



Drywall Compound

# WR Taping Cement

For Superior Adhesion  
In Wet Areas

Specially Formulated  
water based synthetic  
polymer adhesive



# WR Taping Cement

## Description

UPA WR Taping Cement Tape is a specially formulated water based synthetic polymer adhesive used for plasterboard jointing and corner sealing in kitchens, bathrooms and wet areas.

## Applications

Evenly fill all recessed joints and both sides of any corners with UPA WR Taping Cement. Firmly place UPA Perforated Paper Tape on these joints and corners, and firmly bed into WR Taping Cement ensuring all air bubbles are removed. Apply a skim coat of WR Taping Cement over embedded paper tape ensuring the paper tape is completely covered. Cover all fastener heads with WR Taping Cement. Apply a skim coat of WR Taping Cement to the cut edges of plasterboard at sheet junctions with shower bases and baths, feathering out the WR Taping Cement onto the board. Allow 24 hours to dry before tiling.

## Advantages

- Water resistant.
- Smooth and application
- Long-lasting performance.

### UPA Direct

173 Arden Street  
North Melbourne, Victoria 3051 AUSTRALIA  
1300 UPA Direct - 1300 872 347  
Ph: +61 3 9329 2165  
Fax: +61 3 9329 2189